

Anlagenzusammenstellung

Audio, 2-Draht mit Türstationen Sfera robur

2-DRAHT BUS-SYSTEM AUDIO MIT TÜRSTATIONEN SFERA ROBUR																								
Ruftasten	UP-Kasten + Modulträger						Abdeckrahmen			Funktionsmodule			Frontblenden						Netzg.	Konfiguratoren			Hausstationen	
	350010 964 570 190 Mod.	350020 964 570 290 2 Mod.	350030 964 570 390 3 Mod.	350315 964 507 190 1 Mod.	350325 964 507 290 2 Mod.	350335 964 507 390 3 Mod.	350415 964 521 190 1 Mod.	350425 964 521 290 2 Mod.	350435 964 521 390 3 Mod.	351100 964 500 190 TL	352000 964 501 690 4 RT	354000 964 503 490 Kabel	351105 964 513 990 TL	351115 964 514 090 TL + 1 RT	351125 964 514 170 TL + 2 RT	352035 964 515 090 3 RT	352045 964 515 190 4 RT	352305 964 515 590 Leer	346000 964 502 790 NG	306064 964 551 090 10 WE	306065 964 551 290 20 WE	3510/* 964 980 * 90 Konfig.	344252 964 021 200 Classe 100	344082 964 021 000 Polyx Audio
1	1			1			1			1									1				1	1
2	1			1			1			1									1				1	2
3		1			1				1	1					1				1				1	3
4		1			1				1	1					1			1		1			1	4
5		1			1				1	1					1			1		1			1	5
6		1			1				1	1					1			1		1			1	6
7			1			1			1	2					1		1		1				1	7
8			1			1			1	2					1		2		1				1	8
9			1			1			1	2					1		2		1				1	9
10			1			1			1	2					1		2		1				1	10
11		2			2				2	3	1				1		2		1			1	1	11
12		2			2				2	3	1				1		3		1			1	1	12
13		2			2				2	3	1				1		3		1			1	1	13
14		2			2				2	3	1				1		3		1			1	1	14
15			2			2			2	4	1				1		3	1	1			1	1	15
16			2			2			2	4	1				1		4	1	1			1	1	16
17			2			2			2	4	1				1		4	1	1			1	1	17
18			2			2			2	4	1				1		4	1	1			1	1	18
19			2			2			2	5	1				1		4		1			1	1	19
20			2			2			2	5	1				1		5		1			1	1	20
22			2			2			2	5	1				1		5		1	1	1	1	1	22
26			3			3			3	6	2				1		6	2	1			1	1	26
28			3			3			3	7	2				1		7	1	1			2	1	28
32			3			3			3	8	2				1		8		1			2	1	32
36			4			4			4	9	3				1		9	2	1			2	1	36
40			4			4			4	10	3				1		10	1	1			3	1	40
44			4			4			4	11	3				1		11		1			3	1	44
48			5			5			5	12	4				1		12	2	1			3	1	48

* Für mehr als 20 Teilnehmer finden Sie die passende Konfiguratorenanzahl in der Tabelle

Hausstation- Anzahl	KONFIGURATORENANZAHL											
	306064 964 551 090 Set 10 HS	306065 964 551 290 Set 20 HS	3501/0 964 980 090 Konfig. 0 (10 St.)	3501/1 964 980 190 Konfig. 1 (10 St.)	3501/2 964 980 290 Konfig. 2 (10 St.)	3501/3 964 980 390 Konfig. 3 (10 St.)	3501/4 964 980 490 Konfig. 4 (10 St.)	3501/5 964 980 590 Konfig. 5 (10 St.)	3501/6 964 980 690 Konfig. 6 (10 St.)	3501/7 964 980 790 Konfig. 7 (10 St.)	3501/8 964 980 890 Konfig. 8 (10 St.)	3501/9 964 980 990 Konfig. 9 (10 St.)
bis 10	1											
bis 20		1										
bis 29	1	1			1							
ab 30	2	1			1	1						
ab 40	3	1			1	1	1					
ab 50	4	1			1	1	1	1				
ab 60	5	1			1	1	1	1	1			
ab 70	6	1			1	1	1	1	1	1		
ab 80	7	1			1	1	1	1	1	1	1	
ab 90	8	1			1	1	1	1	1	1	1	1

Die Tabelle empfiehlt die Anzahl der Konfiguratoren für Anlagen mit 1 bis 100 Hausstationen und 1 Türstation.